

EN6001



ENTRON

Entron Controls, LLC.
1402 S. Batesville Road
Greer, SC 29650
Phone: 864.416.0190
fax: 864.416.0195

www.EntronControls.com

RWMA[®]
MEMBER

Important Safety Instructions

**READ THIS MANUAL COMPLETELY
BEFORE ATTEMPTING TO INSTALL OR OPERATE THE CONTROL.
STORE THIS TECHNICAL INFORMATION IN A PLACE
TO WHICH ALL USERS HAVE ACCESS AT ANY TIME**

ENTRON Controls follows the practices of the RWMA for precautionary labeling. See RWMA Bulletins #1 and #5 for a complete description. Observe the WARNING, DANGER, and CAUTION labels affixed to control to maintain safe operation. ENTRON Controls, LLC. and its affiliates are not responsible for any harm caused by non-compliance of instructions associated with the aforementioned labels or signal words to follow.

The signal word **DANGER** is used to call attention to immediate or imminent hazards which if not avoided **will result in immediate, serious, or personal injury or loss of life**. Examples are: *exposed high voltage; exposed fan blades*.

The signal word **WARNING** is used to call attention to potential hazards which **could result in personal injury or loss of life**. Examples are: *not using proper personal protection; removal of guards*.

The signal word **CAUTION** is used to call attention to hazards which **could result in non-life threatening personal injury or damage to equipment**. **CAUTION** may also be used to alert against *unsafe practices*.

The term **NOTICE** is used for making recommendations on use, supplementary information, or helpful suggestions. Non-compliance with these recommendations **may result in damage to control, welding machine, or workpiece**. ENTRON Controls, LLC. and its affiliates are not responsible for damage caused by such non-compliance, and warranties may be voided accordingly at the discretion of ENTRON Controls.

WARNING: Individuals with cardiac devices should maintain a safe distance due to strong magnetic fields arising from resistance welding. The function of cardiac pacemakers and defibrillators may be disturbed, which may cause death or considerable health damages to persons concerned! These persons should avoid the welding system unless authorized by a licensed physician.

My Control Information

Filling out the following information (and keeping it readily available) may allow for future technical service of equipment to be conducted more efficiently:

Model #: EN6001
Serial #: _____
OEM/Distributor: _____
Contact #: _____
Purchase Date: _____

Hardware Connections

P1—2, Foot Switch #1 _____
P1—3, Foot Switch #2 _____
P1—4, Emergency Stop _____
P1—5, No Weld Signal _____
P1—6, Programmable Input #1 _____
P1—7, Programmable Input #2 _____
P1—8, Programmable Input #3 _____
P1—9, Programmable Input #4 _____
P1—10, Programmable Input #5 _____
P1—11, Programmable Input #6 _____

P2—2, Solenoid Valve #1 _____
P2—3, Solenoid Valve #2 _____
P2—4, Solenoid Valve #3 _____
P2—5, Programmable Output #1 _____
P2—6, Programmable Output #2 _____
P2—7, Programmable Output #3 _____
P2—8, Programmable Output #4 _____

P3 Sensing Coil Not Used Primary Secondary

Weld Schedule Worksheet

Filling out the following information (and keeping it readily available) may allow for future technical service of equipment to be conducted more efficiently. Please duplicate and complete this page for each utilized schedule:

SCHEDULE #: _____

Squeeze Delay: _____ cycles _____ KVA or _____ %

Squeeze: _____ **cycles** **Valves:** _____

Weld 1: _____ cycles _____ KVA or _____ %

Cool 1: _____ cycles

Slope: _____ cycles

Weld 2: _____ **cycles** _____ **KVA** or _____ **%**

Cool 2: _____ cycles

Impulses: _____ cycles

Hold: _____ **cycles**

Off: _____ **cycles**

Cycle Mode: _____

Comments: _____

Tap Setting: _____ Pressure: _____ Machine: _____

Table of Contents

Functions	6
Specifications	7
Wiring Diagrams	8
Menu Navigation	9
Saving Weld Schedules	10
Loading Weld Schedules	11
Updating Firmware	12
User Connections	13
Weld Timing Cycles	15
Programming Parameters List	16
I/O Map	23
Error List	24
Warranty and Service Policy	27

Functions

- Constant current regulation
- Primary or Secondary feedback
- Current Monitoring with high, low, and pre-limits
- Up to 64 programs (internal or external selection)
- On Timer Membrane Keyboard with backlit 128x64 (8 lines) LCD graphic display
- Six (6) inputs and four (4) outputs with output protection on CPU
- Electrode management functions; including stepping, current counting, tip-dressing, and preset curves
- Welding programs may be linked together for complex spot schedules (chained or successive)
- USB-capable firmware refresh
- AC 60/50 Hz welding support
- Spot / Pulsation / Seam welding / Flash or Butt welding / Brazing
- Multiple weld intervals plus pulsation, upslope and downslope
- Air-over-oil gun operation
- Water Saver (contactor timer)
- Head lock function
- Program lockout (key switch) function
- Operation mode switch (program lockout and Weld/No Weld)
- Error reset switch
- Optional plug-in Ethernet card provides PLC compatibility with Modbus and EtherNet/IP

Specifications

Environmental Conditions:

Operating Temperature	0°C to 60°C
Storage/Transport Temperature	-25°C to 70°C
Air pressure	0 to 2000m above sea level
Humidity	no dew point excursion allowed
Enclosure Ratings	NEMA 1 and NEMA 12

Electronics Ratings:

CPU operating voltage (without I/O)	24 VDC $\pm 5\%$ at 220 mA
Rated current (without I/O) at 24V	SV1-SV3: ~500 mA
	PO1-PO4: ~500 mA


Discrete I/O:

Input	+24V $\pm 15\%$
DC Output	24 VDC, 0.5A max
AC Output	120 VAC, 1A max
Supply I/O:	24 VDC $\pm 5\%$

General Operating:


Operating Voltage (see wiring diagram for details)	240VAC or 380VAC or 480VAC or 575VAC
---	---

Wiring and Connectivity




Menu Navigation


Status Page List (Default)



Main Menu



Schedule Select



AND



Setup Menu




Saving Weld Schedules

Step 1: Insert a formatted USB drive into USB port on the control panel

Step 2: From the 'Setup Menu' (see Menu Navigation for details) select "Utility".




Step 3: Select "Backup data"



Step 4: Rename file (desired) using  and 

Step 5: Set "Confirm" to "YES" using  and 



Step 6: Press  and verify that "DONE!!!" appears in the top left corner of the title bar.




Loading Weld Schedules

Step 1: Insert USB drive with a previously saved backup file* into the USB port on the control panel.

Step 2: From the 'Setup Menu' (see Menu Navigation for details) select "Utility".




Step 3: Select "Restore data"



Step 4: Select the desired filename* using  and 

Step 5: Set "Confirm" to "YES" using  and 



Step 6: Press  and verify that "DONE!!!" appears in the top left corner of the title bar.



*Note: The backup file must be on the root directory of the USB drive. And the filename must be EN6001**00**.EN6 to EN6001**99**.EN6

Updating Firmware

Step 1: Ensure the control is completely powered down.

Step 2: Insert USB drive with EN6001 firmware file into USB port on the control panel.

Step 3: Press and hold  and 

Step 4: Power on the control. Once the Bootloader Menu (shown right) appears, release  and 

Step 5: Select “Refresh firmware”

Step 6: Select the desired filename* using  and 

Step 7: Set “Confirm” to “YES” using  and 

Step 8: Press and  the control will begin updating.

Step 9: In order to return to the “Main Menu”, either


1. Temporarily power down the control

2. Go back to “Bootloader Menu” by pressing  Then, select “Execute firmware”, then select “YES”.


*Note: The firmware file must be on the root directory of the USB drive, and the filename will be E061**1001**.BIN to E061**9999**.BIN (this may requiring the extraction of a zip file)



User Connections (DC)




User Connections (AC option)



<u>Port</u>	<u>Designation</u>	<u>Switch</u>
TS1 - SV1	Solenoid Valve #1	AC Analog
TS1 - SV2	Solenoid Valve #1 Common	0VAC
TS1 - SV3	Solenoid Valve #2	AC Analog
TS1 - SV4	Solenoid Valve #2 Common	0VAC
TS1 - SV5	Solenoid Valve #3	AC Analog
TS1 - SV6	Solenoid Valve #3 Common	0VAC
TS4 - TIMER V3 OUT	Output from P2 - 4 (Valve #3 control signal)	24V Digital
TS4 - V3IN	Optional connection to replace “P2 - 4” signal from timer module with an alternatively desired 24VDC signal. (For example, “P2 - 5” programmed to “Retraction” could be connected when using an AC retraction valve.)	Default - Jumper Connected to TS4 - TIMER V3 OUT
TS7 - B	B ypass Solenoid Valve #3 Safety Relay	Default - JW6 Disconnected
TS7 - R	Solenoid Valve #3 Safety R elay	Default - JW6 Connected

WARNING Bypassing the safety relay will result in the valve 3 control being independent of FS1 or FS2 after initiation. This should NOT be done with valves connected to pinch points such as the primary welding force valve.

Weld Timing Cycle



<u>PARAMETER</u>	<u>SETTING</u>
Squeeze Delay	0 cycles
Squeeze	3 cycles
Weld 1	0 cycles
Cool 1	0 cycles
Slope	0 cycles
Weld 2	2 cycles
>Mode	Phase Shift
>Heat	50 %
Cool 2	1 cycle
Hold	2 cycles
Off	2 cycles
Impulses	2 cycles

The diagram above is intended to demonstrate a resulting welding timing cycle using the attached parameters; it is not recommended as part of a functional weld schedule.

Parameter List

Main Menu

<u>Sub Menu</u>	<u>Parameter</u>	<u>Input Range</u>	<u>Description</u>
1. Use Schedule			
	Schedule	[0-63]	Default = 0
2. Edit Schedule			
	Advance	[0-99] cycles	Default = 0 This option only appears when 'air-over-oil' configuration is selected.
	Intensify	[0-99] cycles	Default = 0 This option only appears when 'air-over-oil' configuration is selected.
	Block Delay	[0-99] cycles	Default = 0 This option only appears when 'air-over-oil' configuration is selected.
	Schedule Number	[0-63]	Default = 0 In order to accept changes made to any field, the  button must be pressed. It is important to make sure that the correct schedule number is selected AND accepted BEFORE completing all of the corresponding settings to follow.
	Squeeze Delay	[0-99] cycles	Default = 0 Additional time delay to be added to 'Squeeze'. This is usually utilized when 'Cycle Mode' is set to repeat. The squeeze delay will only be applied to the first weld of the repeating cycle.
	Squeeze	[0-99] cycles	Default = 0 Time delay between the signal to the programmed valve(s) and weld initiation.
	>Valve	None 1 2 3 1+2 1+3 2+3 1+2+3	Selection of valve(s) to be activated
	Weld 1	[0-99] cycles	Default = 0 Also referred to as "pre-heat"
	>Mode	Phase Shift Const Current	
	>Heat	[0-99] %	Phase shift %; does not apply when 'Mode' is set to Const Current
	or		
	>Current	[0.00-60.00] kA	Weld current setting does not apply when Mode is set to Phase Shift
	>I1 Monitor	On Off	Must be enabled in order to track/report current errors
	>PW1 Monitor	On Off	Must be enabled in order to track/report phase shift abnormalities.
	Cool 1	[0-99] cycles	Default = 0 Time delay between 'Weld 1' and 'Weld 2'. Designed to give an impulse effect.

Parameter List

Main Menu (continued)

<u>Sub Menu</u>	<u>Parameter</u>	<u>Input Range</u>	<u>Description</u>
2. Edit Schedule (continued)			
	Slope	[0-99] cycles	Default = 0 The number of additional cycles between 'Weld 1' and 'Weld 2' in order to transition between the two gradually. A larger 'Weld 1' will result in a downslope; whereas a larger 'Weld 2' will result in an upslope.
	Weld 2	[0-99] cycles	Default = 0
	>Mode	Phase Shift Const Current	
	>Heat	[0-99] %	Phase shift %; does not apply when '>Mode' is set to Const Current
	or		
	>Current	[0.00-60.00] kA	Weld current setting does not apply when Mode is set to Phase Shift
	>I2 Monitor	On Off	Must be enabled in order to track/report current errors
	>PW2 Monitor	On Off	Must be enabled in order to track/report phase shift abnormalities.
	Cool 2	[0-99] cycles	Default = 0 Primarily used when applying multiple impulses; time delay following each 'Weld 2' impulse.
	Hold	[0-99] cycles	Default = 0 Time delay during which the electrodes remain in contact with the part being welded to allow weld nugget to congeal.
	Off	[0-99] cycles	Default = 0 Time delay following 'Hold' cycle in which the valve(s) release; the next schedule/sequence will not begin until the 'Off' cycle is complete.
	Impulses	[1-99] cycles	Default = 1 Number of times to deliver Weld 2, Cool 2. (Impulses do NOT apply to Weld 1, Cool 1)
	I offset	-1 % 0 % +1 %	Adjustable increase or decrease to total current delivered by a sequence. This is one of the few adjustable parameters when control is locked. Parameter is only visible when 'Max I offset' is not "0".
	>Change all	No Yes	No – 'I offset' will be applied to the current schedule Yes – 'I offset' will be applied to all schedules'
	Block Delay	[0-99] cycles	Default = 0 This option only appears when 'air-over-oil' configuration is selected.

Parameter List

Main Menu (continued)

<u>Sub Menu</u>	<u>Parameter</u>	<u>Input Range</u>	<u>Description</u>
2. Edit Schedule (continued)			
	Cycle Mode	Non-Repeat Repeat Chained Successive Wait Here	Non-repeat – Control can be initiated for only one sequence/schedule even if initiation remains closed. Repeat – Sequences/ schedules will continue if initiation remains closed. Chained – Schedules are chained together so that consecutive schedules can be sequenced from one initiation. Successive – Schedules are chained together so that consecutive schedules will be sequenced from separate initiations. Wait-Here – only applies when 'Weld2' is set to 99 cycles. This allows infinite Weld 2 duration until Escape is triggered. 'Beat Mode' is authorized to "Wait-Here" if desired.
3. Copy Schedule			
	Copy From	[0-63]	Schedule # to be copied
	Copy To	[0-63]	Schedule # to be replaced
	Confirm	Yes No	Must select "Yes" and press the  key to complete the above copy/replace. "DONE!!!" appear in the title bar once complete.
4. Reset Error			
	Confirm	Yes No	Must select "Yes" and press the  key to complete the above copy/replace. "DONE!!!" appear in the title bar once complete.
5. Edit Counter			
	Counter	Enable Disable	Enable – 'Weld count done' will increment with each weld delivered. Error "ER25" will be reported when 'Max part count' = 'Part count done'
	Max part Count	[0-60,000]	Default = 60,000 Number at which the 'part count done' reports error "ER25"
	Weld per part	[1-9,999]	Default = 1 The number of welds to increment 'part count done' by one.
	RST Counter	None PCTR WCTR Both	Resets counter PCTR – part counter WCTR – weld counter

Parameter List

Setup Menu

<u>Sub Menu</u>	<u>Parameter</u>	<u>Input Range</u>	<u>Description</u>
1. Config			
	Weld Mode	Spot Seam1 Seam2	Spot – Standard squeeze, weld, hold and off sequence. Seam1 – When FS1 or FS2 input is toggled, control will run 'schedule' from 'Squeeze Delay' through 'Cool 2'. If FS1 or FS2 input is held, control will repeat 'Weld 2' and 'Cool 2'. Seam2–FS1 initiation implements same function as in Seam1. FS2, schedule 20, schedule 40 and schedule 60 will always initiate "Spot" Weld Mode
	Retraction	Off Maintained Momentary	Maintained – Retraction output directly reflects retraction input Momentary – Retraction output changes state with a toggled impulse to the retraction input. This parameter is ignored if 'Beat_Mode' is enabled.
	On Error	Continue Head Lock Stop	Continue – Further welds are permitted regardless of previous weld status Head Lock – On error, valve signal(s) are held on. Additional welds are not permitted until Error Reset occurs. Stop – On error, valve signal(s) turn off as normal. Additional welds are not permitted until Error Reset occurs.
	Sch Select	Internal External	Internal – FS1 will initiate the programmed weld schedule number External – FS1 will initiate the weld schedule number according to the binary value represented by PI3, PI4, PI5, and PI6. (FS2 will always initiate weld schedule 20.)
	I-Feedback	Primary Secondary	This setting should correspond to the physical location of the sensing coil.
	Air-over-oil	Off Mode 1 Mode 2	Mode 1: air-over-oil setting without retraction Mode 2: air-over-oil setting with retraction enabled using 'Retract Open' and 'Retract Close' settings
	Retract Open	[0-99] cycles	Default = 0 Time delay to allow for retraction from "pre-weld" position to "fully open" position Sub Menu only appears when 'air-over-oil' is set to "Mode 2"
	Retract Close	[0-99] cycles	Default = 0 Time delay to allow for closure from "fully open" position to "pre-weld" position Sub Menu only appears when 'air-over-oil' is set to "Mode 2"

Parameter List

Setup Menu (continued)

<u>Sub Menu</u>	<u>Parameter</u>	<u>Input Range</u>	<u>Description</u>
1. Config (continued)			
	Beat mode	Off Squeeze Sqz. + Weld Wait-Here	Off – Sequence/Schedule will complete with a momentary activation of FS1 or FS2 Squeeze – Sequence/Schedule requires continuous activation of FS1 or FS2 until the squeeze sequence is complete, otherwise the sequence will terminate. Sqz. + Weld – Welding sequence requires continuous activation of FS1 or FS2 until the weld sequence is complete, otherwise the sequence will terminate. Wait-Here – Welding sequence requires continuous activation of FS1 or FS2 until the weld sequence is complete, otherwise the sequence will temporarily pause (retraction will not occur). This setting requires the active schedule's 'Cycle Mode' to also be set to "Wait-Here".
	AVC	Disabled Max [1-10] %	Automatic Voltage Compensation – Will add additional percentage to phase shift in order to compensate for diminished supply voltage. (only works with schedules using "Phase Shift" Mode to regulate current)
	AVC nom.	[187-633] volts	Default = 480 Supply voltage on which the control is designed to operate. Parameter is only visible when 'AVC' is enabled.
	Voltage monitor	Off On	On – High and Low Voltage errors are enabled using the following parameters.
	>High	[160-690] volts	Default = 690 Error "ER23" will be triggered if supply voltage is above the set value Parameter is only visible when 'Voltage Monitor' is "On"
	>Low	[160-690] volts	Default = 160 Error "ER24" will be triggered if supply voltage is below the set value Parameter is only visible when 'Voltage Monitor' is "On"
	Max I offset	[0-15] %	Determines the input range for 'I offset' parameter. For example, if 'Max I offset' is 6%, 'I offset' input range is -6% to +6%
	Water Saver	[0-199] sec	Default = 0 Time duration that the water flow signal will remain on following a weld. Feature available on PO4
	87° delay	Off On	On – The first half cycle is delayed 87degrees (51.6% max) phase shift in order to minimize saturation of the weld transformer
	Half Cycle	Off + - AC	+ – Only the positive half cycle is output - – Only the positive half cycle is output AC – Alternating positive/negative half cycles are output

Parameter List

Setup Menu (continued)

<u>Sub Menu</u>	<u>Parameter</u>	<u>Input Range</u>	<u>Description</u>
1. Config (continued)			
	Power factor	[0-99] %	Default = 75 0 – "Automatic Power Factor" mode 1-99 – Manual power factor delay. Value must be determined by the Power Factor Delay and will vary for each machine. If a primary or secondary coil is NOT installed, a manual power factor of 80% is recommended. Automatic Power Factor may react abnormally if enabled without a coil.
	Blanking	[0-99] cycles	Default = 0 The number of weld cycles to exclude from measurement and limit testing
	Display return	[0-10] min	Default = 0 0 – Disabled Length of time before the display returns to 'Status Page 1'
	Clear	None I/O Map Calibration Config Stepper Counter Schedule All	Clearing data from this menu does not require a confirmation. "DONE!!!" will appear in the title bar as verification.
2. Calibration			
	Toroid	[135-165] mV/kA	Default = 150 For accurate current monitoring
	Max I	[20-60] kA	Default = 20
	AC line scale	[0.8-1.2]	Default = 1.0 For accurate voltage monitoring
3. I/O Map	(see page 23)		
4. Error Map	(see page 24)		
5. Stepper			
	Stepper	Disable Heat	Heat – Stepper function enabled with current compensation
	Tip dress	[0-9,999]	Default = 9,000 When 'Count Done'='Tip dress', error (ER31) will trigger
	RST stepper	No Yes	Selecting "Yes" and pressing the  key will reset the 'Count done' to zero

Parameter List

Setup Menu (continued)

<u>Sub Menu</u>	<u>Parameter</u>	<u>Input Range</u>	<u>Description</u>
5. Stepper (continued)			
	[01-10]:Count	[0-9,999]	Default = 0 The number of welds required to move onto the next step
	>Heat+	[0-99] %	Default = 0 Additional phase shift to be added to Weld 1 and Weld 2 'Heat' settings Only applies when the weld 'Mode' is set to "Phase Shift."
	>Current+	[0.00-99.99] kA	Default = 0 Additional current to be added to Weld 1 and Weld 2 'Current' settings Only applies when the weld 'Mode' is set to "Const Current."
6. Utility			
	Backup Data	(see page 10)	
	Restore Data	(see page 11)	

I/O Map

Setup Menu (continued)

<u>Input/Output</u> (Location)	<u>Options</u> Default	<u>Description</u>
PI1 (P1 - 6)	TT1 2nd stage Back step PCTR	TT1 – Temperature Limit Switch (also called TLS) 2nd stage – FS1/FS2 activates valve closure only; 2nd Stage input initiates weld Back step – Return to previous schedule in “Successive” Cycle mode PCTR – Part counter reset
PI2 (P1 - 7)	Edit lock PS1 Interlock WCTR Reset	Edit lock – closed = control locked; open = control unlocked PS1 – Pressure switch signal Interlock – Signal to authorize weld; used with PO4 Interlock WCTR – Weld counter reset
PI3 (P1 - 8)	Error reset Sch. Select 1 Stepper reset 2nd Stage	Error reset – Clear error in order resume function Sch. Select 1 – Binary value of “one” for externally selecting schedule Stepper reset – Return stepper to “Zero” position 2nd stage – FS1/FS2 activates valve closure only; 2nd Stage input initiates weld
PI4 (P1 - 9)	Interlock Sch. Select 2 Error Reset (Not Used)	Interlock – Signal to authorize weld; used with PO4 Interlock Sch. Select 2 – Binary value of “two” for externally selecting schedule Error reset – Clears error in order resume function
PI5 (P1 - 10)	Back step Sch. Select 4 Retraction (Not Used)	Back step – Return to previous schedule in “Successive” Cycle mode Sch. Select 4 – Binary value of “four” for externally selecting schedule Retraction – Retract input command for release of valves
PI6 (P1 - 11)	Stepper Reset Sch. Select 8 Edit lock Escape	Stepper reset – Return stepper to “Zero” position Sch. Select 8 – Binary value of “eight” for externally selecting schedule Edit lock – closed = control locked; open = control unlocked Escape – Command to escape current weld schedule/sequence
PO1 (P2 - 5)	Any Error Retraction Force Error Major Error	Any Error – Major or minor error is detected Retract Output – Command to retract (in addition to programmed valves) Force Error – Pressure switch is not detecting proper electrode force Major Error – Major error detected; determined by “Error Map” settings
PO2 (P2 - 6)	AVC Error Contactor Error Step End EOS	AVC Error – Automated Voltage Compensation is insufficient Contactor Error – Energy is being shunted; (typically set to trip a breaker) Step End – Programmable step has completed its count EOS – 0.5sec signal at the end of each weld sequence
PO3 (P2 - 7)	Current Error Any Error Count end Water Saver	Current Error – Constant Current Control in insufficiently compensating Any Error – Major or minor error is detected Count end – ‘Max part count’ has been reached Water Saver – signal turns off after a set time following the last weld
PO4 (P2 - 8)	Step End Current Error AVC Error Interlock	Step End – Programmable step has completed its count Current Error – Constant Current Control in insufficiently compensating AVC Error – Automated Voltage Compensation is insufficient Interlock – “Request to weld” signal from external source; used with PI4

Error List

Note: All error defaults are set to “Minor error”. Error handling should be set under the configurations menu and by utilizing the “Any Error”, “Contactor Error”, and “Major Error” options available for the programmable outputs in the I/O Map.

ERROR CODE

- | | |
|----|--|
| 1 | Configuration error
Invalid data in the ‘Config’ menu. Review programming |
| 2 | Calibration error
Invalid data in the ‘Calibration’ menu. Review programming |
| 3 | Schedule error
Invalid data in the ‘Edit Schedule’ menu. Review programming |
| 4 | Sequencer error
Invalid data in the ‘Sequencer’ menu. Review programming |
| 6 | Counter error
Invalid data in the ‘Counter’ menu. Review programming |
| 7 | Stepper error
Invalid data in the ‘Stepper’ menu. Review programming |
| 8 | I/O Map error
Invalid data in the ‘I/O Map’ menu. Review programming |
| 9 | E-Stop error
The input is not seeing a closed signal from the Emergency Stop Switch. If this feature is unused, insert a jumper from ‘P1-1’ to ‘P1-4’. If the feature is being utilized, verify that E-Stop is functioning appropriately. |
| 10 | TC1 error
The ‘TLS’ input on the power board is not seeing a closed signal from the contactor’s Thermal Limit Switch. If this feature is unused, insert a jumper from between the two TLS connections on the power board. If the feature is being utilized, verify that the SCR is not overheating. |
| 11 | No Weld error
The input is not seeing a closed signal from the external “No Weld” driver. If this feature is unused, insert a jumper from ‘P1-1’ to ‘P1-5’. If the feature is being utilized, verify that external driver is functioning appropriately. |
| 12 | PS1 error
The input is not seeing a closed signal from the external pressure switch. If this feature is unused, program ‘PI2’ to another option or insert a jumper from ‘P1-7’ to ‘P1-12’. If the feature is being utilized, verify that valve and pressure switch are functioning appropriately. |
| 13 | SCR short
Check SCR or weld transformer wiring. |
| 14 | Second Stage error
Control has timed out waiting for 2nd Stage input. Verify connection and signal to PI1 or PI3. |
| 15 | TT1 Error
The input is not seeing a closed signal from the Transformer Thermal Limit Switch. If this feature is unused, program ‘PI1’ to another option or insert a jumper from ‘P1-6’ to ‘P1-12’. If the feature is being utilized, verify that the transformer is not overheating. |

Error List

ERROR CODE

- 16 Interlock Error
Control has timed out waiting for Interlock input. If this feature is unused, program 'PI2' and/or 'PI4' to another option or insert a jumper from 'P1-7' and/or 'P1-9' to 'P1-12'. If the feature is being utilized, verify that the external weld interlock is functioning appropriately.
- 19 High Current 1
The control measured a higher current for Weld1 than the programmed upper limit. Verify that the impedances are normal and/or consider changing the programmed value under the 'Edit Schedule' menu.
- 20 Low Current 1
The control measured a lower current for Weld1 than the programmed lower limit. Verify that the impedances are normal and/or consider changing the programmed value under the 'Edit Schedule' menu.
- 21 High Current 2
The control measured a higher current for Weld2 than the programmed upper limit. Verify that the impedances are normal and/or consider changing the programmed value under the 'Edit Schedule' menu.
- 22 Low Current 2
The control measured a lower current for Weld2 than the programmed lower limit. Verify that the impedances are normal and/or consider changing the programmed value under the 'Edit Schedule' menu.
- 23 High Voltage
The AC line voltage is measured above the programmed upper limit under the "voltage monitor" parameter. Check the AC line voltage and/or adjust the parameter under the 'Config' menu.
- 24 Low Voltage
The AC line voltage is measured below the programmed lower limit under the "voltage monitor" parameter. Check the AC line voltage and/or adjust the parameter under the 'Config' menu.
- 25 Counter end
Reset the counter. If this feature is not being utilized, consider disabling it under the 'Edit Counter' menu.
- 26 Stepper end
Reset Stepper. If this feature is not being utilized, consider disabling it under the 'Stepper' menu.
- 27 High Pulse Width1
The pulse width for Weld 1 was above the programmed upper limit. Check transformer or secondary circuit to ensure that current is not shunting and/or adjust parameter under the 'Edit Schedule' menu.
- 28 Low Pulse Width1
The pulse width for Weld 1 was below the programmed lower limit. Check transformer or secondary circuit and/or adjust parameter under the 'Edit Schedule' menu.
- 29 High Pulse Width2
The pulse width for Weld 2 was above the programmed upper limit. Check transformer or secondary circuit to ensure that current is not shunting and/or adjust parameter under the 'Edit Schedule' menu.

Error List

ERROR CODE

- 30 Low Pulse Width2
The pulse width for Weld 2 was below the programmed lower limit. Check transformer or secondary circuit and/or adjust parameter under the 'Edit Schedule' menu.
- 31 Tip dress pre-warn
Dress tip
- 32 AVC error
Check AC line voltage and/or adjust the parameters under the 'Config' menu.
- 33 Starts/Retract @ RST
FS1, FS2, or PI5 programmed to retract was activated when the control was reset.
Check the signals to ensure they are working properly.
- 34 SYNC error
The control cannot synchronize with the AC line voltage. Check AC line frequency.
- 35 PNW error
The front panel's 'Weld/No Weld' button is currently set to 'No Weld'.
- 36 DC Safety Relay error
The safety relay for the DC valves is not properly corresponding with the input commands. This could imply a hardware issue with the control.
- 37 AC Safety Relay error
The safety relay for the AC valves is not properly corresponding with the input commands. This could imply a hardware issue with the control.
- 43 Pre-high current1
The control measured a higher current for Weld1 than the programmed upper pre-limit. Verify that the impedances are normal and/or consider changing the programmed value under the 'Edit Schedule' menu.
- 44 Pre-low current1
The control measured a lower current for Weld1 than the programmed lower pre-limit. Verify that the impedances are normal and/or consider changing the programmed value under the 'Edit Schedule' menu.
- 45 Pre-high current2
The control measured a higher current for Weld2 than the programmed upper pre-limit. Verify that the impedances are normal and/or consider changing the programmed value under the 'Edit Schedule' menu.
- 46 Pre-low current2
The control measured a lower current for Weld2 than the programmed lower pre-limit. Verify that the impedances are normal and/or consider changing the programmed value under the 'Edit Schedule' menu.
- 59 Retract input closed
Retraction mode is set to "Momentary" which programs the control to expect a short toggle to activate a response. The momentary toggle has remained high for 10 seconds or more. Check the signal to PI5 to ensure proper function.
- 60 PS1 not ready
Control is waiting for a closed signal from the external pressure switch.
- 61 Retract not ready
Control is waiting for a closed retraction input to PI5
- 62 2nd Stage not ready
Control is waiting for a closed input to PI1 or PI3 for weld initiation.
- 64 Interlock not ready
Control is waiting for a closed interlock input to PI2 or PI4.

Warranty and Service Policy

Warranty:

ENTRON warrants that any equipment manufactured by it for the Purchaser (the “Product”) will be free from defects in materials and workmanship and will comply with ENTRON’s quoted specification and/or schematic design for the Product (the “Designed Use”). ENTRON further warrants that, if properly and normally used and maintained, the Product will be free of defects for the Warranty Period. The Warranty Period shall run from the date of original purchase of the Product to the earlier of (i) eighteen (18) months after the date of shipment from the ENTRON site or (ii) twelve (12) months after the Product is placed in service, whichever occurs first (the “Warranty Period”). The Warranty Period applies unless superseded by a different term that is expressly accepted by ENTRON in writing in ENTRON’s order acknowledgement document. During the Warranty Period, ENTRON will remedy any such defects and will remedy any non-compliance with the quoted specification and/or schematic design by repair or replacement (at ENTRON’s option) of the Product or parts to the Product.

Terms and Conditions of Warranty:

The warranty shall be limited to the warranty of materials and workmanship and compliance with ENTRON’s Designed Use for the Product and ENTRON makes no other warranties. When the Product is sold to be used in combination with other equipment not of ENTRON’s design or manufacture, the warranty is limited to the Product and not the other equipment.

EXCEPT FOR THE WARRANTY SET FORTH ABOVE IN THE FIRST PARAGRAPH, (A) NEITHER ENTRON NOR ANY PERSON ON ENTRON’S BEHALF HAS MADE OR MAKES ANY EXPRESS OR IMPLIED REPRESENTATION OR WARRANTY WHATSOEVER, EITHER ORAL OR WRITTEN, INCLUDING ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, OR NON-INFRINGEMENT OR PERFORMANCE OF PRODUCTS OR PRODUCTS TO STANDARDS SPECIFIC TO THE COUNTRY OF IMPORT, WHETHER ARISING BY LAW, COURSE OF DEALING, COURSE OF PERFORMANCE, USAGE OF TRADE OR OTHERWISE, ALL OF WHICH ARE EXPRESSLY DISCLAIMED, AND (B) THE PURCHASER ACKNOWLEDGES THAT IT HAS NOT RELIED UPON ANY REPRESENTATION OR WARRANTY MADE BY ENTRON, OR ANY OTHER PERSON ON ENTRON’S BEHALF, EXCEPT AS SPECIFICALLY PROVIDED IN THE FIRST PARAGRAPH.

This warranty does not apply to any Product that (i) has been subjected to abuse, misuse, neglect, negligence, accident, improper testing, improper installation, improper storage, improper handling, abnormal physical stress, abnormal environmental conditions or use contrary to any instructions issued by ENTRON; (ii) has been reconstructed, repaired or altered by persons other than ENTRON or its authorized representative; (iii) has been used or integrated into any machine or equipment for any use other than a Designed Use; or (iv) has been used with any third-party products, hardware or product that has not been previously approved in writing by ENTRON.

For replacement parts supplied by ENTRON, the Warranty Period for said replacement parts is limited to the Warranty Period for the original Product in which said replacement parts are installed.

With respect to any of the equipment used within the Product, but not manufactured by ENTRON, ENTRON will transmit to the Purchaser the benefit of any warranties or conditions it receives from the manufacturer or supplier of said equipment which are capable of transmission. ENTRON itself gives no warranty hereunder in respect of any such equipment.

To obtain repairs or replacement parts under this warranty, the defective part must be returned, prepaid, to any ENTRON site (Mexico, United Kingdom or United States) prior to the end of the Warranty Period. Please send your repair to the attention of “Service” with a description of the problem you are experiencing, contact person and phone number.

Warranty and Service Policy

Limitations of the Warranty:

The damages for which ENTRON is liable in respect of any one cause of action shall not exceed the sum equal to 100% of the purchase price specified in the equipment purchase agreement.

OTHER THAN ACTUAL DAMAGES AS LIMITED BY THE PRIOR PARAGRAPH, IN NO EVENT SHALL ENTRON OR ITS REPRESENTATIVES BE LIABLE FOR CONSEQUENTIAL, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, PUNITIVE OR ENHANCED DAMAGES, LOST PROFITS OR REVENUES OR DIMINUTION IN VALUE, ARISING OUT OF OR RELATING TO ANY CLAIMS RELATED TO THE PRODUCT, REGARDLESS OF (A) WHETHER SUCH DAMAGES WERE FORESEEABLE, (B) WHETHER OR NOT PURCHASER WAS ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND (C) THE LEGAL OR EQUITABLE THEORY (CONTRACT, TORT OR OTHERWISE) UPON WHICH THE CLAIM IS BASED, AND NOTWITHSTANDING THE FAILURE OF ANY AGREED OR OTHER REMEDY OF ITS ESSENTIAL PURPOSE. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, THE PURCHASER ASSUMES ALL RISK AND LIABILITY FOR THE RESULTS OBTAINED BY THE USE OF ANY PRODUCTS IN THE PRACTICE OF ANY PROCESS, WHETHER IN TERMS OF OPERATING COSTS, GENERAL EFFECTIVENESS, SUCCESS OR FAILURE, AND REGARDLESS OF ANY ORAL OR WRITTEN STATEMENTS MADE BY ENTRON OR ITS AUTHORIZED REPRESENTATIVE, BY WAY OF TECHNICAL ADVICE OR OTHERWISE, RELATED TO THE USE OF THE PRODUCT.

Warranty and Transferability of Software:

All software and/or software documentation (collectively, the "Software"), whether supplied to the Purchaser as a component of the Product or supplied as a stand-alone Product, shall be considered to be "licensed" rather than "sold" to the Purchaser, and the Purchaser shall be licensed to use the Software under the following terms unless superseded by a different term that is expressly accepted by ENTRON in writing in ENTRON's order acknowledgement document.

ENTRON or ENTRON's licensor retains ownership of the Software and applicable copyrights, patents and trade secrets.

- The Purchaser, as licensee, is granted a limited, non-exclusive, royalty-free license to use the Software during the term permitted by ENTRON in writing (and perpetually for any Software embedded into the Product).
- The Purchaser may not reverse engineer or modify the Software (except to customize the Product for the Purchaser's operations, as authorized by ENTRON in writing, provided that any such modifications are and shall remain the property of ENTRON), remove it from the Product, or install the Software into products other than the Product.
- The Purchaser may not sublicense the Software, and this license terminates upon transfer of the Product to any third party.

All rights in the Software not expressly granted hereunder are reserved to ENTRON. The rights granted herein may be terminated by ENTRON upon prior written notice to the Purchaser if the Purchaser is in default of these standard terms.

ENTRON Document 750003-0414