

**APPLICATION NOTE 700214B**  
**CHANGE VALVE TRANSFORMER IN**  
**T/D CABINET FROM 150 VA TO 500 VA**

Reference also 510247-004 for dimensions

To replace 150 VA Valve Transformer with 500 VA Valve Transformer:

1. Remove ALL power to control. Open door.
2. Mark and then remove wires from 150 VA Valve Transformer. Remove transformer.
3. Use 510247-004 to modify cabinet for 500 VA Valve Transformer. Be sure to vacuum or otherwise remove ALL metal chips after modification.
4. Install 500 VA Valve Transformer with 4 ea. 10-32 x ½ Machine Screws, Flat Washers, Lock Washers, and Nuts, supplied by ENTRON. Attach wires to terminals in accordance with the Wiring Diagram.
5. Close door, reapply power.